

WATER SAFE®

ASSEMBLY INSTRUCTIONS for LIFT OFF ENCLOSURES WITH END LOCKING BRACKET

1. Center a minimum 4" thick concrete base around the installed device placing expansion material around the riser pipes. Recommended concrete pad sizes: **WS-2FMYA/P 30"x 21"**; **WS-SP1/P 43"x 20"**
2. Center the stainless steel mounting bracket around the riser pipes: front to back and left to right.
3. Drill 1/4" holes in concrete with masonry bit using the holes in the bracket as a guide. Insert and set hit pins.
4. Set enclosure and slide into slots in stainless steel mounting bracket. Insert padlock (by others) on other end.

